

PROGRAMMING YOUR REMOTE

Step 1: Finding the Gateway ID.

- Press MENU (or the wrench button) on the gateway cable box, and a gray screen will appear.
- Using the arrows on the gateway move down to REMOTE CONTROL SETUP and press SELECT (or the box with an 'X' in it) on the gateway. Another gray screen will appear.
- Press the PPV button on the remote.
- Write down the 3-digit Gateway ID. _____ (If there are fewer than 3 digits add zeros to the beginning - e.g. 8 becomes 008)

Step 2: Programming the Gateway ID.

- Press and hold the 'B' button until the red light flashes.
- Press 7-8-9.
- Press the 3-digit Gateway ID. (the red light will flash and go off)

Step 3: Programming the Remote Control ID.

- Press and hold the 'A' button until the red light flashes.
- Press 7-8-9.
- Enter the correct number from below
 - 1 for TV1 (TV that is set to Channel 4)
 - 2 for TV2 (TV that is set to Channel 7)
 - 3 for TV3 (TV that is set to Channel 13)

Step 4: Programming the TV Code.

- Press and hold the MUTE button until the red light flashes.
- Press the green POWER button.
- Pointing at the TV continue to press and release the UP ARROW until the TV powers off.
- Once the TV powers off press the SELECT button.

NOTE: If you press the UP ARROW too quickly you may pass the Code before you press select. If this happens do Step 4 again, but press the down button slowly until the TV powers off.